

Installation Instructions

MUST BE FITTED TO A SOLID WALL OR OTHER FIRM SURFACE.

For fixing to timber, use only hexagon coach screws. For fixing to brickwork, block work or concrete, use the hexagon coach screws with 10mm wall plugs or equivalent.

Grade 304 Stainless Steel M8 x 75 mm hexagon coach screws supplied and 10 mm wall plugs supplied.



Accessible –
Install seat as per AS 1428.1

Design for Access and Mobility. When in the horizontal position ensure seat does not present a hazard and the grab rail is accessible.



Fixing –

Drill spot marks with 10 mm bit. Plug and screw seat to wall using the 304 Stainless Steel M8 x 75 mm hexagon coach screws supplied.



Positioning –

In the horizontal position, level check and spot mark wall through seat frame mount holes.



Checking –

Check seat is firmly secured to wall and the Tension Grip Hinge screws are appropriate for ease of movement.

Starion
delivering design excellence

7 Eagleview Place | PO BOX 1163 | EAGLE FARM QLD 4009
Phone: (07) 3131 5800 (Brisbane metro) | 1800 060 875 (Outside Brisbane metro)
Fax: (07) 3131 5957 (Brisbane metro) | 1800 805 829 (Outside Brisbane metro)
Email: info@starionaust.com.au
Web: www.starionaust.com.au