
INSTALLATION INSTRUCTIONS MILANO CLOSE COUPLED TOILET SUITES



PRODUCTMilano S Trap Close Coupled SuiteJ1424CODES:Milano P Trap Close Coupled SuiteJ1425

The Milano CC suites are WELS 4 Star rated with 4.5/3L Dual Flush Cistern water inlet is on right side of tank - installer changeable to the left



INSTALLATION STEPS

Before You Start

- Inspect all components for any transit damage before starting installation. If damaged or faulty do not install, contact your supplier.
- Check site roughing in, water supply position and assembly dimensions before commencing installation.

Fixing the WC Pan

- Always check the installation of the suite with the cistern fitted before permanently fixing down. The WC pan must be installed level with the cistern flush against the wall.
- The WC can be installed by setting in a mortar bed or using screw fixings.(fixings not supplied)
- For mortar bedding use a 4:1 sand and standard cement mix (do not use Rapid Hardening or White cement). If the floor is tiled, cut out the tiles beneath the pan to create a good bonding surface.
- When using fixing screws a waterproof sealant may be applied to the pan base before locating it in the correct position. Always use protective plastic bushes with the fixing screws. Do not over-tighten the screws.
- In all installations take care to ensure that the pan connector is correctly sealed to the pan outlet spigot.

Fitting the Cistern

- Remove the cistern lid and turn the cistern upside down and check that the inlet and outlet valve securing nuts are firmly tightened to prevent leaks-do not overtighten.
- Fit the foam sealing ring evenly over the flush valve outlet.
- Fit the two fixing bolts to the slots in the metal mounting plate on the underside of the cistern tank.
- Lower the cistern carefully into position on the WC pan locating the bolts through the holes at the back of the pan. Check that the foam seal is seated correctly. Tighten the fixing nuts evenly by hand until the cistern is firmly mounted and level on the WC pan.

OUTLET VALVE BUNG METAL MOUNTING PLATE REAR OF FIXING BOLTS REAR OF FIXING BOLTS


Water Connection


- Always flush the water supply pipes before connecting the cistern inlet valve. If using 15mm copper pipe for connection ensure that this is inserted less than 9mm into the inlet valve socket otherwise the water flow rate may be restricted.
- Fill the cistern, and check the water level, if necessary adjust to the 4.5L fill mark on the back wall of the cistern.
- Attach the cistern lid and button assembly and test flush several times while checking for leaks at the pan connector and the cistern/pan connection.
- Fit the seat


VALVE SERVICE

INLET VALVE SERVICE

1. Major water level adjustment











WARNING


marbletrend

DO NOT USE CHLORINE/CHEMICAL SANITISERS IN THE CISTERN TANK. SUCH USE MAY RESULT IN DAMAGE TO TANK COMPONENTS AND WILL VOID THE PRODUCT WARRANTY

2. Minor water level adjustment








With a screwdriver adjust the float - the top of the float(A) should be 2-4mm below the level of the top of the float cup(B)

3. Cleaning the valve diaphragm

It is possible for dirt/debris to prevent the valve from shutting off.

To remedy this the diaphragm may be cleaned as follows:


- 1. Remove the cover cap
- $2.\,Unclip\,the\,float\,arm\,from\,the\,adjustment\,screw$
- 3. Twist the plastic top-asembly firmly anti-clockwise and remove it from the valve body
- 4. Inspect both rubber diaphragm and valve seat. Rinse under running water to remove dirt/debris
- 5. Re assemble in reverse order



OUTLET VALVE SERVICE








Hoses are not shown on this diagram

Push button rod settings

Button rods must be just clear of




Button rods can be adjusted by screwing up or down




Ensure that buttons match valve pads

Half flush adjustment



Half flush volume can be adjusted by moving the side float up or down. Moving the float DOWN increases the half flush Moving the float UP decreases the half flush

Full flush adjustment



The full flush volume can be adjusted by changing the residual water level in the cistern. Move the adjuster DOWN to increase the volume.

Move the adjuster UP to decrease the volume.

Tel: 1300 717 717 Fax: 1300 746 480 www.johnsonsuisse.com.au

Bathroom Products Australia Pty Ltd ABN 87 079 297 617 2/97 Banksia St Botany NSW 2019