

# caroma® TASMAN II –DELUXE SHOWER SET

## WATER EFFICIENT TAPWARE

(NOMINAL FLOW RATE = 8 L/min)

### PLUMBERS INSTALLATION INSTRUCTIONS

#### Important Information

- \* Shower outlet is fitted with an 9 L/min flow regulator.
- \* Not suitable for gravity feed systems.
- \* All pipework must be thoroughly flushed prior to installation, as foreign materials may block the flow regulating device and reduce the flow of water.

#### Installation

- 1) Check that the face of the recess tap body (1) is between 0–13mm from the wall/tile face, as shown in Fig. 1.
- 2) Check seats in recess tap bodies (1) are in good condition and free of foreign materials. Reseat if required.
- 3) Fully open tap spindle (3) in tap head assembly (2). Ensure fibre washer and jumper valve are in position as shown.
- 4) Screw tap head assembly (2) into recess tap body (1) by hand and tighten using suitable tube spanner.
- 5) Screw flange (5) onto plastic insert (4) then screw on wall the assembly and tighten fully by hand against wall/tile face taking care not to damage the decorative finish.
- 6) Fit handle assembly as follows:–
  - i) Turn both spindles to the fully off position.
  - ii) Fit handle (6) directly onto spindle (3).
  - iii) Screw button (7) onto spindle (3) and tighten firmly against handle (6), using spanner (8) provided.
- 7) Check that threaded nipple (10) is the correct length, as shown. Cut to length if required ensuring end face is square. Apply thread tape to the thread.  
**Important :** Care must be taken that thread tape cannot become dislodged and block the flow regulating device, causing a reduction in water flow.
- 8) Place the cover plate (9) over the threaded nipple (10). Screw the inlet socket (11) onto the threaded nipple (10) and position shower as required. DO NOT OVERTIGHTEN.




Fig. 1

IS8205A(12/10)