

PLUMBERS INSTALLATION INSTRUCTIONS

Installation

- 1) Check in-wall depth (dimension 'A' in Fig. 1) to ensure correct length spindle (3) has been selected (see Table 1).
- 2) Check seats in recess tap bodies (1) are in good condition and free of foreign materials. Reseat if required.
Important : All pipework must be thoroughly flushed prior to installation, to remove all foreign matter.
- 3) Fully open tap spindle (3) in tap head assembly (2). Ensure fibre washer and jumper valve are in position as shown.
- 4) Screw tap head assembly (2) into recess tap body (1) by hand and tighten using suitable tube spanner.
- 5) Screw on wall flange (4) and tighten fully by hand against wall/tile face taking care not to damage the decorative finish.
- 6) Fit handle assembly as follows:-
 - i) Turn both spindles to the fully closed position.
 - ii) Place retaining nut (6) over spindle (3), with slot facing flange (4).
 - iii) Place retaining clip (7) into groove at bottom of spline in spindle (3).
 - iv) Ensure handle insert (8) is in position in handle (9). Fit handle (9) to spindle (3), position to suit. Push handle (9) firmly down until it bottoms internally.
 - v) Screw retaining nut (6) into handle and tighten using spanner (5) provided.
- 7) Check that threaded nipple (10) is the correct length, as shown. Cut to length if required ensuring end face is square. Apply thread tape to the thread. Screw the bath outlet (11) onto the threaded nipple (10) and position as required. **DO NOT OVERTIGHTEN** .




Fig. 1

IMPORTANT

Pressure & Temperature Requirements.

- Hot and cold water inlet pressures should be equal.
- Static inlet pressure range : 150 -1000 kPa
New Regulation :-500 kPa maximum static pressure at any outlet within a building.
(Ref. AS/NZS 3500.1-2003, Clause 3.3.4)
- Maximum hot water temperature : 80°C.

Table 1

Dimension 'A'	Tap Head Ass'y	Dimension 'B'
0 - 13mm	Standard Length	92.5mm
13 - 26mm	13mm Extended	105.5mm